

FIG. 1
(PRIOR ART)




FIG. 2




FIG. 3

REFRESH COMMAND SIGNAL	BANK COMBINATION CASE 1				BANK COMBINATION CASE 2				BANK COMBINATION CASE 3			
	BA2	BA1	BA0	REFRESH -ING BANK	BA2	BA1	BA0	REFRESH -ING BANK	BA2	BA1	BA0	REFRESH -ING BANK
AUTOMATIC REFRESH	0 0	0 0	1 X	0, 1	0 0	1 X	0 0	0, 2	1 X	0 0	0 0	0, 4
AUTOMATIC REFRESH	0 0	0 1	0 X	2, 3	0 0	0 X	0 1	1, 3	0 X	0 0	0 1	1, 5
AUTOMATIC REFRESH	0 1	0 0	0 X	4, 5	0 1	0 X	0 0	4, 6	0 X	0 1	0 0	2, 6
AUTOMATIC REFRESH	0 1	0 1	0 X	6, 7	0 1	0 X	0 1	5, 7	0 X	0 1	0 1	3, 7